

1 HP 37717B ATM Operating Features

Introduction to ATM	1-1
Physical Measurements	1-1
ATM Layer measurements - Out-of-Service.	1-1
Header Errors	1-1
Cell Errors	1-2
Cell Loss	1-2
Cell Misinsertion	1-2
Cell Transfer Delays	1-2
Cell Delay Variation (CDV)	1-2
1-point CDV	1-3
Cell Delay Variation (CDV) and Non-Conforming Cell Count	1-4
What problems does it cause?	1-4
How can CDV be controlled?	1-4
How can CDV be measured?	1-4
What is a GCRA?	1-5
Constant Bit Rate Application of the GCRA.	1-5
Non-Constant Bit Rate Application of the GCRA.	1-6
Using the 1-Point CDV measurement.	1-6
Analyze the Traffic CDV Profile.	1-6
Verify the Policing Function.	1-7
Traffic Simulation	1-7
OAM Cell Generation	1-9
Distribution Types	1-9
Alarms	1-9
ATM Layer Alarms	1-9
Operation During Alarm Conditions	1-11
HP 37717B ATM Measurement	1-12
Cell Level ATM Testing. Option UKN (USE)	1-12
HP 37717B ATM Features	1-13
Cell Level ATM (Options UKN (USE)	1-13
Traffic Simulation	1-13

Contents

The Test Cell	1-15
Trail Trace	1-16
Alarm and Error Generation	1-16
HEC Errors	1-17
Payload Errors	1-17

2 ATM Testing with the HP 37717B

In-Service Testing	2-1
ATM Layer Testing	2-1
Cell Layer Error Measurement	2-3
Default (Known State) Settings	2-3
ATM In-Service Test Setup Procedure, SDH Interface Example	2-3
Run the In-service ATM Test	2-4
Out of-Service Testing	2-5
ATM Cell Performance Test	2-5
Application	2-5
Default (Known State) Settings	2-5
ATM Cell Performance Test Setup Procedure	2-5
Start the ATM Cell Performance Test	2-9
At the End of the Test (ATM Cell Performance)	2-10
Cell Routing Test	2-11
Cell Congestion Test	2-12
Cell Sync and Header Error Correction Test	2-14
Checking Single Header Error Performance	2-14
Checking Double Header Error Performance	2-15
Constant Bit Rate Service Assessment	2-16
Alarm Testing	2-17