

OPERATING AND CALIBRATION MANUAL

HP 3784A

DIGITAL TRANSMISSION ANALYZER

SERIAL NUMBERS

This manual applies directly to instruments with serial numbers prefixed 2902U.

For additional important information about serial numbers, see INSTRUMENTS COVERED BY MANUAL in Section 6.

© Copyright HEWLETT-PACKARD LIMITED 1989
SOUTH QUEENSFERRY, WEST LoTHIAN, SCOTLAND

Manual Part Number: 03784-90000
Microfiche Part Number: 03784-90025

Printed: April 1989

Contents

Chapter 1	Page
Introduction to the HP 3784A Digital Transmission Analyzer	1-1
Description	1-1
 Chapter 2	 Page
Getting Started	2-1
Introduction	2-1
Instrument Turn On	2-1
Procedure	2-1
Operating The HP 3784A	2-3
HP 3784A Display At Switch-On	2-3
Making your first Measurement	2-3
Selecting An Index Or Page	2-8
PAGE Keys	2-8
Controlling The Cursor	2-9
Changing User Selectable Functions/Parameters	2-10
Front Panel Operating Features	2-11
Front Panel Input/Output Ports	2-13
Alarms	2-15
Rear Panel Input/Output Ports	2-16
Self Test Features	2-18
Option Instruments	2-18
Default Settings	2-18
 Chapter 3	 Page
Making Measurements with the HP 3784A	3-1
Introduction	3-1
What Measurements does the HP 3784A perform?	3-1
Error Measurements	3-1
Error Analysis Measurements	3-2
Alarm Duration Measurements	3-2
Slip Measurement	3-3
Jitter Measurements (Option 002 instruments)	3-3
64 kbit/sec Codirectional Interfaces (Option 006)	3-3
Making a Measurement	3-4
Transmitter Setup	3-4
Receiver Setup	3-4
Gating	3-4

Contents (continued)

Measurements and Results.....	3-5
Storing Measurement Configuration.....	3-5
Receiver Auto-Configure.....	3-5
Making Out-of-Service Error Measurements.....	3-7
Bit Error Measurement on Coded Ternary Data.....	3-7
Code Error Injection and Measurement.....	3-8
Bit Error Ratio Measurement at Binary TTL Interfaces.....	3-9
Bit Error Count Measurement at Binary TTL Interfaces.....	3-10
Making In-Service Code Error Measurements.....	3-12
In-Service Measurements.....	3-12
Code Error Measurement on Live Traffic - In-service.....	3-12
Monitor Mode.....	3-12
Error Analysis Measurements.....	3-14
Analysis PASS/FAIL Thresholds.....	3-14
Error Analysis Example.....	3-15
Additional Measurements.....	3-16
Using Zerosubstitution.....	3-16
Frequency Measurement.....	3-17
Frequency Offset Measurements.....	3-17
AIS Pattern Generation and Detection.....	3-18
Storing and Recalling Measurement Configurations.....	3-19
To Store Configuration in Preset Panel.....	3-19
To Recall Set-up from Panel Memory.....	3-19
Jitter Measurements - Option 002.....	3-20
Practical Jitter Measurements.....	3-20
Jitter Transfer Function.....	3-21
Jitter Tolerance Measurement.....	3-21
HP 3784A Jitter Generation and Measurements.....	3-22
Jitter Generation.....	3-22
THRU DATA Mode.....	3-22
Transmitter Jitter Modulation.....	3-23
Internal Modulation.....	3-23
Swept and Spot Mask Modulation.....	3-23
External Modulation.....	3-24
Jitter Measurement.....	3-25
Measurement Filters.....	3-25
Intrinsic Jitter Performance.....	3-25
Jitter Measurement Display Update Rates.....	3-25
Jitter Measurements on a Binary Clock Signal.....	3-26
HP 3784A Output Jitter Measurement.....	3-27
In-Service Output Jitter Measurements.....	3-28
Jitter Analysis Measurement.....	3-28
HP 3784A Jitter Tolerance Measurements.....	3-29
Jitter Tolerance Measurement at a Number of Jitter Points.....	3-29
Jitter Tolerance Measurement using "Spots" on Jit. Mask.....	3-29
Jitter Tolerance Measurement using Swept Mask Modulation.....	3-29
Automatic Jitter Tolerance Plotting.....	3-29
How to Make a Jitter Tolerance Measurement.....	3-30

How to Make an Automatic Jitter Tolerance Measurement	3-32
HP 3784A Jitter Transfer Function Measurement	3-34
How To Make A Jitter Transfer Function Measurement	3-34
How to Make an Automatic Transfer Function Measurement	3-35
Alternate Word Pattern Generation	3-36
HP 3784A OPT 006 - 64 kbit/s Measurements	3-37
Practical Measurements at 64 kbit/s Codirectional Interfaces	3-38
Plesiochronous Timing	3-38
Synchronous Timing - Looped	3-39
Synchronous Timing - External Clock	3-40

Chapter 4

Page Function Description

Page

	4-1
Introduction	4-1
Store and Recall Measurement Configurations (Page 1)	4-1
Tx Setup (Page 2)	4-4
Rx Setup (Page 3)	4-7
Measurements (Page 4)	4-10
How to Control Measurement Gating (Page 5)	4-13
Alarms (Page 6)	4-15
Data Logging (Page 7)	4-16
Remote Control (Page 8)	4-22
Logging Port (Page 9)	4-28
Rear Panel Ports (Page 10)	4-29
Real Time Clock and Calendar (Page 11)	4-31
Self-test (Page 12)	4-32

Chapter 5

Data Logging

Page

	5-1
Introduction	5-1
Recommended Printers	5-1
Applications of Data Logging	5-1
Connecting the HP 3784A to a Printer	5-2
Quick Guide to Data Logging with the HP 3784A	5-5
Logging Bit Error Measurement Results	5-7
Graphics Mode	5-10
Log Code Error Results Graphically	5-13
Results Printed in Real Time	5-15
Counts/Second	5-15
Page 4 Results Explained	5-16
End of Period Results Summary Explained	5-17
What Triggers Logging?	5-20

Contents (continued)

Log On Demand	5-22
What Stops Logging?	5-23
Squelch	5-23
External Triggering (option 002 only)	5-24

Chapter 6	Page
General Information	6-1

Introduction	6-1
Specifications	6-1
Safety Considerations	6-1
Instruments Covered By Manual	6-2

Chapter 7	Page
Installation	7-1

Introduction	7-1
Initial Inspection	7-1
Contents	7-1
Preparation For Use	7-2
Power Requirements	7-2
Line Voltage Selection	7-2
Power Cable	7-2
HP 3784A Display Contrast Adjustment	7-3
Internal Battery	7-3
Battery Failure	7-3
Operating Environment	7-4
Storage and Shipment	7-4
Environment	7-4
Rack Mounting	7-5
Packaging	7-7
Hewlett-Packard Interface Bus (HP-IB) Installation	7-8
Connection To The HP-IB	7-8
HP-IB Cables	7-9
RS-232-C Interface Installation	7-10
Connection to the RS-232-C System	7-10
Logic Levels	7-10
RS-232-C Remote Control	7-10

Chapter 8	Page
Performance Tests	8-1
Introduction	8-1
Equipment Required.....	8-1
Test Record.....	8-2
Calibration Cycle.....	8-2
Performance Test Contents.....	8-2
Operation Verification	8-2
Self Tests.....	8-2
Instrument Default Settings.....	8-2
External Clock.....	8-3
Internal Clock and Frequency Offset.....	8-5
Binary Clock and Data Outputs	8-8
Transmitter n-Bit Programmable Word.....	8-10
Transmitter Pattern Trigger	8-12
Transmitter PRBS Pattern Verification.....	8-14
Transmitter Alternating Word.....	8-16
Ternary Data Outputs	8-18
Bit and Code Error Add.....	8-22
Receiver Binary Data and Clock	8-24
Receiver Clock Recovery.....	8-26
Ternary Data Input Levels.....	8-28
Reference WORD and Synchronization.....	8-30
Receiver Reference PRBS Patterns and Zero Substitution	8-31
Receiver Autoconfigure and AIS Indication	8-34
Measurement Gating and Power Loss Alarm.....	8-36
Error Out	8-37
Receiver Error Detection and Measurement	8-39
HP-IB Verification.....	8-41
External Modulation Input (Option 002)	8-42
Int Mod and Demod Jitter Measurement In (Opt 002)	8-50
Performing Jitter Self Tests (Option 002).....	8-55
Thru data (Option 002).....	8-57
64 kbit/s Co-directional Interface (Option 006)	8-60

Appendix A	Page
Measurement Definitions	A-1
Introduction	A-1
Measurements.....	A-1
Error Measurements.....	A-1
Error Count.....	A-1
Error Ratio.....	A-1
Error Intervals.....	A-1
Error Free Intervals.....	A-2

Contents (continued)

Error Analysis:	A-2
Availability*	A-2
Unavailability:	A-2
Error Seconds*	A-3
% Severely Errored Seconds*	A-3
Degraded Minutes*	A-3
Error Distribution:	A-3
Error Bursts:	A-3
Long Term Mean Error Ratio:	A-4
GO/NO GO Tests:	A-4
Loss Measurements:	A-4
Power Loss	A-4
AIS:	A-4
Sync. Loss:	A-5
Data Loss: (Ternary Mode)	A-5
Rx Clock Loss: (Binary & Thru-data only)	A-5
Tx Clock Loss:	A-5
Slip Count	A-5
Frequency and Offset:	A-6
Offset Measurement Range:	A-6
Offset Measurement Resolution:	A-6
Frequency Measurement Resolution:	A-6
Accuracy: (Binary or Ternary):	A-6
Options	A-6
Option 002:	A-6
Automatic Tolerance Plotting:	A-6
Automatic Jitter Transfer Function Plotting:	A-7
Standard Tolerance Masks:	A-7
Programmable Tolerance Masks:	A-8
Receiver Display Rates:	A-8
Internal Filtering:	A-8
Max. Peak-Peak:	A-8
Hit Count:	A-9
Sensitivity:	A-9
Threshold Range:	A-9
Hit Intervals:	A-9
Hit Free Intervals:	A-9
Measurement In:	A-9
Warning/Indicator Lamps:	A-9
Jitter Unlock	A-9
Hits	A-10
Bounds Indicators	A-10

Appendix B	Page
Glossary Of Terms	B-1

Appendix C	Page
Operating Notes	C-1

Introduction	C-1
Selecting Jitter Measurements	C-1
Selecting Thrudata	C-1
Selecting Codirectional Interface	C-1
Monitor Code Errors Alarm Led	C-1
Measuring Received Jitter in Thrudata Mode	C-2
Interface Choices	C-2
Tx Jitter Amplitude p-p (option 002)	C-2
Optimum Jitter Intrinsic Performance	C-2
Avoiding Timing Problems	C-2
Selecting Jitter Masks	C-2
RX REF CLOCK IN	C-3

Appendix D	Page
Operator Selectable Switches In The HP 3784A	D-1

Appendix E	Page
Panel Memory Record Sheet	E-1

Introduction	E-1
--------------------	-----

Appendix F	Page
Error Codes	F-1

Introduction	F-1
CPU Selftest	F-1
RS-232 Modem Port Selftest	F-1
RS-232 Printer Port Selftest	F-1
Clock Synthesiser Selftest	F-1
Jitter Selftest	F-2
BER Self Test	F-2
Table of Error Codes	F-2