
Table Of Contents

General Safety Summary	ix
Preface.....	xii

EXTERNAL CONTROLLERS & PRINTERS

Remote Control Applications.....	1-1
Printer Applications.....	1-1
Using the RS-232C Port.....	1-1
Using the GPIB Port	1-6

REMOTE COMMANDS

Command Types & Syntax	2-1
Command Symbols and Delimiters.....	2-1
Multiple Commands.....	2-2
Arguments	2-2
Table of Commands	2-5
Standard Commands.....	2-12
General Setup Commands	2-20
Test Cycle Control Commands	2-23
System Configuration.....	2-27
Receiver Remote Commands	2-30
Rx Mapping.....	2-31
Pointers	2-32
B1, B2, B3, Payload Bit, Path REI, FEBE, TSE Error Data Query Commands.....	2-33
RS-B1, MS-B2, and MS-REI Error Data Query Commands.....	2-36
SDH Error Status.....	2-52
SONET Error Status.....	2-52
LED Status Query Commands	2-53
Transport Overhead Bytes.....	2-61
Automatic Protection Switching (APS) Data.....	2-65
Receiver Drop Commands	2-65
Transmitter Remote Commands.....	2-67
External Tributary Insertion Channel Commands	2-73
Single-Error Insertion Commands	2-74
Error Rate Commands	2-75
TOH Edit and Query Commands	2-79
Alarms	2-85
Repeat Alarms.....	2-89
Loss of Signal.....	2-91

Combined (Dual Mode) Commands.....	2-93
------------------------------------	------

APPENDICES

LabView Drivers	A-1
LabWindow Drivers.....	B-1
SDH for Reference	D-1
SONET for Reference	E-1
SDH Glossary and ITU-T Standards.....	G-1
SONET Glossary	H-1