
Contents

1 Before You Start . . .

Introduction 1-2

Getting Started 1-3

How to Use This Guide 1-3

New Users 1-3

What You Should Understand 1-3

Learning to Program the Counter 1-4

Experienced Programmers 1-4

Applications 1-5

Programming Guide Contents 1-6

Assumptions 1-6

Related Documentation 1-7

2 Commands Summary

Introduction 2-2

Chapter Summary 2-2

Front Panel to SCPI Command Maps 2-3

HP 53181A Command Summary 2-16

SCPI Conformance Information 2-16

IEEE 488.2 Common Commands 2-17

HP 53181A SCPI Subsystem Commands 2-20

Std/New Column 2-20

Parameter Form Column 2-20

***RST Response** 2-32

3 Programming Your Counter for Remote Operation

Introduction 3-2

Chapter Summary 3-2

Where to Find Some Specific Information 3-2

Where to Find HP BASIC Programming Examples 3-3

Where to Find QuickBASIC Programming Examples 3-3

Where to Find Turbo C Programming Examples 3-3

Contents

Configuring the HP-IB 3-4

- To Set the HP-IB Mode and Address 3-4
- To Connect the Counter to a Computer 3-6
- Remote/Local Operation 3-6

Overview of Command Types and Formats 3-7

- Common Command Format 3-7
- SCPI Command and Query Format 3-7

Elements of SCPI Commands 3-8

- Subsystem Command Syntax 3-8
- Common Command Syntax 3-8
- Abbreviated Commands 3-9
- Keyword Separator 3-9
- Optional Keyword 3-10
- Parameter Types 3-11
- Parameter Separator 3-12
- Query Parameters 3-12
- Suffixes 3-12
 - Suffix Elements 3-12
 - Suffix Multipliers 3-13
- Command Terminator 3-13

Using Multiple Commands 3-14

- Program Messages 3-14
- Program Message Syntax 3-14

Overview of Response Message Formats 3-16

- Response Messages 3-16
- Response Message Syntax 3-16
- Response Message Data Types 3-18

Status Reporting 3-20

- Status Byte Register and Service Request Enable Register 3-22
 - Status Byte Register 3-22
 - Service Request Enable Register 3-24
- Standard Event Status Register Group 3-25
 - Standard Event Status Register 3-25
 - Standard Event Status Enable Register 3-28

Contents

Operation Status Register Group and Questionable Data/Signal Status Register Group 3-28

- Condition Register 3-30
- Transition Filter 3-30
- Event Register 3-31
- Event Enable Register 3-31
- Operation Status Register Group 3-32
- Questionable Data/Signal Status Register Group 3-34

Command Settings for Optimizing Throughput 3-37

- Commands to Set Counter for Optimal Throughput 3-37
- Typical Optimizing Throughput Results for Different Computers 3-39

How to Program the Counter for Status Reporting 3-40

- Determining the Condition of the Counter 3-40
- Resetting the Counter and Clearing the HP-IB Interface—
Example 1 3-40
- Using the Standard Event Status Register to Trap an Incorrect
HP-IB command—Example 2 3-41
 - Event Status Register 3-41
- Using the Questionable Data/Signal Status Register to Alert the
Computer When Automatic Interpolator Calibration is Disabled—
Example 3 3-41
 - Questionable Data Status Register 3-42
- Using the Operation Status Register to Alert the Computer When
Measuring has Completed—Example 4 3-42
 - Operation Status Register 3-42

How to Program the Counter to Display Results 3-45

- Configuring the Counter's Display 3-45
- Commands for Displaying Non-Scaled/Offset Results 3-45
- Commands for Displaying Scaled/Offset Results 3-46
- Commands for Displaying the Limit Graph 3-46
- Commands for Displaying Statistics Results 3-46
- Commands for Enabling and Disabling the Display 3-47

How to Program the Counter to Synchronize Measurements 3-48

- Synchronizing Measurement Completion 3-48
- Resetting the Counter and Clearing the HP-IB Interface 3-48
- Using the *WAI Command 3-48
- Using the *OPC? Command 3-49
- Using the *OPC Command to Assert SRQ 3-50

Contents

How to Program the Counter for Math/Limit Operations	3-51
Updating Math and Limit Results Over HP-IB	3-51
Using the Scale and Offset Over HP-IB	3-52
How to Program the Counter to Define Macros	3-54
Writing SCPI Programs	3-57
Programming Examples	3-60
Using HP BASIC	3-60
To Send a Double-Quoted String	3-60
To Send a Single-Quoted String	3-60
Using QuickBASIC	3-61
Using Turbo C	3-61
List of the Programming Examples	3-61
Easiest Way to Make a Measurement (HP BASIC)	3-62
To Make a Frequency Measurement (HP BASIC)	3-64
To Perform Limit Testing (HP BASIC)	3-65
To Measure the Statistics of 50 Measurements (HP BASIC)	3-66
To Use Limits to Filter Data Before Measuring Stats (HP BASIC)	3-68
To Read and Store Calibration Information (HP BASIC)	3-70
To Optimize Throughput (HP BASIC)	3-71
To Use Macros (HP BASIC)	3-73
To Make a Frequency Measurement (QuickBASIC)	3-75
To Perform Limit Testing (QuickBASIC)	3-76
To Measure the Statistics of 50 Measurements (QuickBASIC)	3-78
To Use Limits to Filter Data Before Measuring Stats (QuickBASIC)	3-80
To Read and Store Calibration Data (QuickBASIC)	3-82
To Optimize Throughput (QuickBASIC)	3-83
To Use Macros (QuickBASIC)	3-85
To Make a Frequency Measurement (Turbo C)	3-88
To Use Limits to Filter Data Before Measuring Statistics (Turbo C)	3-90
To Optimize Throughput (Turbo C)	3-93

Contents

4 Commands Reference

Introduction 4-2

:ABORt 4-4

:CALCulate Subsystems 4-5

:CALCulate[1] Subsystem 4-7

:CALCulate[1]:DATA? 4-7
:CALCulate[1]:FEED "[[:SENSe[1]]]" 4-8
:CALCulate[1]:IMMediate 4-8
:CALCulate[1]:IMMediate:AUTO 4-9
:CALCulate[1]:MATH Subtree 4-9
 :CALCulate[1]:MATH[:EXPRession]:CATalog? 4-9
 :CALCulate[1]:MATH[:EXPRession][:DEFine]? 4-10
 :CALCulate[1]:MATH[:EXPRession]:NAME
 SCALE_OFFSET 4-10
 :CALCulate[1]:MATH[:EXPRession]:SELEct
 SCALE_OFFSET 4-10
:CALCulate[1]:MATH:STATe 4-10

:CALCulate2 Subsystem 4-11

:CALCulate2:FEED "[[:CALCulate[1]]]" 4-11
:CALCulate2:IMMediate 4-11
:CALCulate2:IMMediate:AUTO 4-12
:CALCulate2:LIMIT Subtree 4-12
 :CALCulate2:LIMIT:CLEar:AUTO 4-13
 :CALCulate2:LIMIT:CLEar[:IMMediate] 4-13
 :CALCulate2:LIMIT:DISPlay 4-13
 :CALCulate2:LIMIT:FAIL? 4-14
 :CALCulate2:LIMIT:FCOunt:LOWer? 4-15
 :CALCulate2:LIMIT:FCOunt[:TOTal]? 4-15
 :CALCulate2:LIMIT:FCOunt:UPPer? 4-15
 :CALCulate2:LIMIT:LOWer[:DATA] 4-16
 :CALCulate2:LIMIT:PCOunt[:TOTal]? 4-17
 :CALCulate2:LIMIT:STATe 4-17
 :CALCulate2:LIMIT:UPPer[:DATA] 4-18

Contents

:CALCulate3 Subsystem	4-19
:CALCulate3:AVERage Subtree	4-19
:CALCulate3:AVERage:ALL?	4-19
:CALCulate3:AVERage:CLEar	4-20
:CALCulate3:AVERage:COUnT	4-20
:CALCulate3:AVERage:COUnT:CURRent?	4-21
:CALCulate3:AVERage[:STATe]	4-21
:CALCulate3:AVERage:TYPE	4-22
:CALCulate3:DATA?	4-22
:CALCulate3:FEED "[[:CALCulate[1]]]"	4-23
:CALCulate3:LFIltEr Subtree	4-23
:CALCulate3:LFIltEr:LOWer[:DATA]	4-23
:CALCulate3:LFIltEr:STATe	4-24
:CALCulate3:LFIltEr:UPPer[:DATA]	4-24
:CALCulate3:PATH?	4-25
:CALibration Subsystem	4-26
:CALibration[:ALL]?	4-26
:CALibration:COUnT?	4-26
:CALibration:DATA	4-27
:CALibration:SECurity Subtree	4-28
:CALibration:SECurity:CODE	4-28
:CALibration:SECurity:STATe	4-28
:CONFigure Subsystem	4-30
Device Clear	4-31
:DIAGnostic Subsystem	4-32
:DIAGnostic:CALibration:INPut[1]:GAIN:AUTO	4-32
:DIAGnostic:CALibration:INPut[1]:OFFSet:AUTO	4-33
:DIAGnostic:CALibration:INterpolator:AUTO	4-33
:DIAGnostic:CALibration:ROSCillator:AUTO	4-34
:DIAGnostic:CALibration:STATus?	4-34
:DIAGnostic:MEASure:RESolution?	4-35

Contents

:DISPlay Subsystem	4-36
:DISPlay:ENABle	4-36
:DISPlay:MENU[:STATe] OFF	4-36
:DISPlay[:WINDow]:TEXT:FEED	4-37
:DISPlay[:WINDow]:TEXT:MASK	4-38
:DISPlay[:WINDow]:TEXT:RADix	4-39
:FETCh Subsystem	4-40
:FORMat Subsystem	4-41
:FORMat[:DATA]	4-41
Group Execute Trigger(GET)	4-42
:HCOPy Subsystem	4-43
:HCOPy:CONtinuous	4-43
:INITiate Subsystem	4-44
:INITiate:AUTO	4-44
:INITiate:CONtinuous	4-44
:INITiate:IMMediate	4-46
:INPut[1] Subsystem	4-48
:INPut[1]:ATTenuation	4-48
:INPut[1]:COUPling	4-48
:INPut[1]:FIltEr[:LPASs][:STATe]	4-48
:INPut[1]:FIltEr[:LPASs]:FREQuency?	4-49
:INPut[1]:IMPedance	4-49
:INPut2 Subsystem	4-50
:INPut2:COUPling?	4-50
:INPut2:IMPedance?	4-50
:MEASure Subsystem	4-51
Measurement Instructions	4-52
:CONFigure	4-53
:CONFigure?	4-54
:FETCh	4-55
:MEASure	4-56

:READ	4-57
:MEASure[:SCALar][:VOLTage]:FREQuency?	4-59
:MEASure[:SCALar][:VOLTage]:FREQuency:RATio?	4-61
:MEASure[:SCALar][:VOLTage]:MAXimum?	4-62
:MEASure[:SCALar][:VOLTage]:MINimum?	4-62
:MEASure[:SCALar][:VOLTage]:PERiod?	4-63
:MEASure[:SCALar][:VOLTage]:PTPeak?	4-64
Using :MEASure	4-65
Using :CONFigure with :READ?	4-66
Using :CONFigure with :INITiate and :FETCh?	4-66
:MEMory Subsystem	4-68
:MEMory:DELete:MACRo	4-68
:MEMory:FREe:MACRo?	4-68
:MEMory:NSTATes?	4-68
[:SENSe] Subsystem	4-69
[:SENSe]:DATA? ["[:SENSe(1)"]]	4-69
[:SENSe]:EVENt(1) Subtree	4-69
[:SENSe]:EVENt(1):HYSTeresis:RELative	4-69
[:SENSe]:EVENt(1):LEVel[:ABSolute]	4-70
[:SENSe]:EVENt(1):LEVel[:ABSolute]:AUTO	4-71
[:SENSe]:EVENt(1):LEVel:RELative	4-71
[:SENSe]:EVENt(1):SLOPe	4-72
[:SENSe]:EVENt2 Subtree	4-72
[:SENSe]:EVENt2:LEVel[:ABSolute]?	4-72
[:SENSe]:EVENt2:SLOPe?	4-73
[:SENSe]:FREQuency Subtree	4-73
[:SENSe]:FREQuency:ARM Subtree	4-73
[:SENSe]:FREQuency:ARM[:STARt]:SLOPe	4-73
[:SENSe]:FREQuency:ARM[:STARt]:SOURce	4-74
[:SENSe]:FREQuency:ARM:STOP:DIGits	4-74
[:SENSe]:FREQuency:ARM:STOP:SLOPe	4-75
[:SENSe]:FREQuency:ARM:STOP:SOURce	4-75
[:SENSe]:FREQuency:ARM:STOP:TIMER	4-75
[:SENSe]:FREQuency:EXPEcted(1 2)	4-76
[:SENSe]:FREQuency:EXPEcted(1 2):AUTO	4-77
[:SENSe]:FUNctioN[:ON]	4-77

[:SENSe]:ROSCillator Subtree	4-79
[:SENSe]:ROSCillator:EXTernal:CHECK	4-79
[:SENSe]:ROSCillator:EXTernal:FREQuency?	4-79
[:SENSe]:ROSCillator:SOURce	4-80
[:SENSe]:ROSCillator:SOURce:AUTO	4-80
:STATus Subsystem	4-82
:STATus:OPERation Subtree	4-82
:STATus:OPERation:CONDition?	4-82
:STATus:OPERation:ENABLE	4-83
:STATus:OPERation[:EVENt]?	4-83
:STATus:OPERation:NTRansiion	4-84
:STATus:OPERation:PTRansiion	4-84
:STATus:PRESet	4-85
:STATus:QUEStionable Subtree	4-86
:STATus:QUEStionable:CONDition?	4-86
:STATus:QUEStionable:ENABLE	4-87
:STATus:QUEStionable[:EVENt]?	4-87
:STATus:QUEStionable:NTRansiion	4-88
:STATus:QUEStionable:PTRansiion	4-88
:SYSTem Subsystem	4-90
:SYSTem:COMMunicate Subtree	4-90
:SYSTem:COMMunicate:SERial:CONTRol:DTR	4-90
:SYSTem:COMMunicate:SERial:TRANsmiit:BAUD	4-91
:SYSTem:COMMunicate:SERial:TRANsmiit:PARity[:TYPE]	4-92
:SYSTem:COMMunicate:SERial:TRANsmiit:PACe	4-92
:SYSTem:ERRor?	4-92
:SYSTem:KEY	4-94
:SYSTem:KEY:LOG?	4-95
:SYSTem:VERSion?	4-95
:TRACe Subsystem	4-96
:TRACe:CATalog?	4-96
:TRACe[:DATA] OFFSET	4-96
:TRACe[:DATA]? OFFSET	4-96
:TRACe[:DATA] SCALE	4-97
:TRACe[:DATA]? SCALE	4-97
:TRIGger Subsystem	4-98
:TRIGger:COUNt:AUTO	4-98

Contents

*CAL?(Calibration Query)	4-99
*CLS(Clear Status Command)	4-100
*DDT(Define Device Trigger Command)	4-101
*DMC(Define Macro Command)	4-102
*EMC(Enable Macro Command)	4-103
*EMC?(Enable Macro Query)	4-103
*ESE(Standard Event Status Enable Command)	4-104
*ESE?(Standard Event Status Enable Query)	4-104
*ESR?(Event Status Register Query)	4-106
*GMC?(Get Macro Contents Query)	4-107
*IDN?(Identification Query)	4-108
*LMC?(Learn Macro Query)	4-109
*OPC(Operation Complete Command)	4-110
*OPC?(Operation Complete Query)	4-111
*OPT?(Option Identification Query)	4-112
*PMC(Purge Macro Command)	4-113
*RCL(Recall Command)	4-114
*RST(Reset Command)	4-116
*SAV(Save Command)	4-117
*SRE(Service Request Enable Command)	4-119
*SRE?(Service Request Enable Query)	4-119
*STB?(Status Byte Query)	4-120
*TRG(Trigger Command)	4-121
*TST?(Self-Test Query)	4-122
*WAI(Wait-to-Continue Command)	4-123

Contents

5	Errors
	Introduction 5-2
	Displaying Errors 5-2
	Reading an Error 5-2
	Error Queue 5-3
	Error Types 5-4
	No Error 5-4
	Command Error 5-4
	Execution Error 5-5
	Device- or Counter-Specific Error 5-5
	Query Error 5-6

Index