

Contents

1. General Information	
INTRODUCTION	1-1
USING THE HP 87512A/B	1-1
INSTRUMENTS COVERED BY MANUAL	1-2
DESCRIPTION AND OPERATING CHARACTERISTICS OF THE INSTRUMENT	1-2
OPTIONS	1-2
Option 910, Extra Operation Manual (HP Part Number 87511-90000)	1-2
ACCESSORIES	1-4
Accessories Supplied	1-4
Accessories Available	1-4
Calibration and Accessory Kits	1-4
Cable Sets	1-4
OPERATING AND SAFETY PRECAUTIONS	1-5
Operating	1-5
Service	1-5
RECOMMENDED TEST EQUIPMENT	1-5
SPECIFICATIONS	1-6
OPERATING CHARACTERISTICS	1-6
Definitions	1-6
2. Installation	
INTRODUCTION	2-1
INITIAL INSPECTION	2-1
ENVIRONMENTAL CONSIDERATIONS	2-2
Operating and Storage	2-2
PREPARATION FOR USE	2-2
Connecting the Test Kit	2-2
Mating Connectors	2-3
Power and Control Connections	2-3
PACKAGING	2-3
3. Operation	
INTRODUCTION	3-1
TYPICAL MEASUREMENT SETUP	3-2
One Port Measurements	3-2
One Port Calibration	3-2
Reflection Coefficient/Return Loss	3-3
Complex Impedance	3-3
Two Port Measurements	3-3
Two Port Calibration	3-3
Transmission Measurements	3-3

4. Operational Verification	
INTRODUCTION	4-1
VERIFICATION CYCLE	4-1
EQUIPMENT REQUIRED	4-1
INSERTION LOSS TEST WITH AN HP 8751A	4-3
Test Equipment	4-3
Procedure	4-3
INSERTION LOSS TEST WITHOUT AN HP 8751A	4-5
Test Equipment	4-5
Procedure	4-5

5. Service

A. Manual Changes

Introduction	A-1
MANUAL CHANGES	A-1
Change 1	A-1
Page 1-3, Table	A-1
Page 1-6, Table 1-2 Specifications	A-2
Page 1-6, Table 1-3 Operating Characteristics	A-2
Page 2-1, Table 2-1 Contents of the HP 87512A/B	A-2
Page 5-3, Table 5-1. HP 87512A Signal Divider Replaceable Parts Lists	A-2
Page 5-3, Table 5-2. HP 87512B Signal Divider Replaceable Parts Lists	A-2

Figures

1-1. HP 87512A/B Transmission/reflection Test Kit with Accessories Supplied	1-3
2-1. Test Kit Connections	2-2
3-1. Test Kit Features	3-1
3-2. Typical Measurement Setup	3-2
4-1. Insertion Loss Test Setup With an HP 8751A	4-4
4-2. Insertion Loss Test Without an HP 8751A Setup	4-5
5-1. HP 87512A/B Signal Divider Exploded View	5-2

Tables

1-1. Accessories Available	1-4
2-1. Contents of the HP 87512A/B	2-1
4-1. Recommended Test Equipment	4-2
5-1. HP 87512A Signal Divider Replaceable Parts Lists	5-3
5-2. HP 87512B Signal Divider Replaceable Parts Lists	5-3
A-1. Manual Changes by Serial Number	A-1