

Table of Contents

General Safety Summary	ix
Preface	xi
Related Manuals	xi
Default Model	xii
Model References	xii
Conventions	xii

Getting Started

Product Description	1-1
Differences by Model	1-2
Product Specification	1-2
Start Up	1-3
Preparation	1-3
Putting into Service	1-4

Operating Basics

Overview	2-1
Operating Interface Maps	2-3
Tutorial	2-9
Setting Up for the Examples	2-9
Example 1: Displaying a Waveform	2-13
Example 2: Displaying Multiple Waveforms	2-15
Example 3: Taking Automated Measurements	2-19
Example 4: Saving Setups	2-24

Reference

Overview	3-1
Acquiring and Displaying Waveforms	3-3
Coupling Waveforms to the Oscilloscope	3-3
Setting up Automatically: Autoset and Reset	3-6
Selecting Channels	3-8
Scaling and Positioning Waveforms	3-10
Choosing an Acquisition Mode	3-17
Customizing the Display	3-29
Customizing the Display Color	3-34
Zooming on Waveforms	3-39
Using InstaVu [®] Acquisition Mode (TDS 500B and 700A Models Only)	3-45
Using FastFrame [®] (TDS 500B and 700A Models Only)	3-48
Triggering on Waveforms	3-51
Triggering Concepts	3-51
Triggering from the Front Panel	3-55
Triggering on a Waveform Edge	3-59

Triggering Based on Logic	3-62
Triggering on Pulses	3-72
Delayed Triggering	3-84
Measuring Waveforms	3-91
Taking Automated Measurements	3-91
Taking Cursor Measurements	3-101
Taking Graticule Measurements	3-105
Optimizing Measurement Accuracy: SPC and Probe Cal	3-106
Saving Waveforms and Setups	3-115
Saving and Recalling Setups	3-115
Saving and Recalling Waveforms	3-118
Managing the File System	3-121
Printing a Hardcopy	3-125
Communicating with Remote Instruments	3-134
Determining Status and Accessing Help	3-139
Displaying Status	3-139
Displaying Help	3-141
Using Features for Advanced Applications	3-143
Limit Testing	3-143
Waveform Math	3-148
Fast Fourier Transforms	3-150
Waveform Differentiation	3-167
Waveform Integration	3-171

Appendices

Appendix A: Options and Accessories	A-1
Appendix B: Algorithms	B-1
Appendix C: Packaging for Shipment	C-1
Appendix D: Factory Initialization Settings	D-1
Appendix E: Probe Selection	E-1
Appendix F: Inspection and Cleaning	F-1

Glossary

Index

01-E
11-E
21-E
31-E
41-E
51-E
61-E
71-E
81-E
91-E
CC-E

List of Figures

Figure 1-1: Rear Panel Controls Used in Start Up	1-5
Figure 1-2: ON/STBY Button	1-6
Figure 2-1: Connecting a Probe for the Examples (P6245 shown) ..	2-9
Figure 2-2: SETUP Button Location	2-10
Figure 2-3: The Setup Menu	2-10
Figure 2-4: Trigger Controls	2-11
Figure 2-5: The Display After Factory Initialization	2-12
Figure 2-6: The VERTICAL and HORIZONTAL Controls	2-13
Figure 2-7: TRIGGER Controls	2-14
Figure 2-8: AUTOSET Button Location	2-14
Figure 2-9: The Display After Pressing Autoset	2-15
Figure 2-10: Display Signals Requiring Probe Compensation	2-15
Figure 2-11: The Channel Buttons and Lights	2-16
Figure 2-12: The Vertical Main Menu and Coupling Side Menu	2-17
Figure 2-13: The Menus After Changing Channels	2-18
Figure 2-14: Measure Main Menu and Select Measurement Side Menu	2-20
Figure 2-15: Four Simultaneous Measurement Readouts	2-21
Figure 2-16: General Purpose Knob Indicators	2-22
Figure 2-17: Snapshot of Channel 1	2-23
Figure 2-18: Save/Recall Setup Menu	2-25
Figure 3-1: How Probe Compensation Affects Signals	3-4
Figure 3-2: P6139A Probe Adjustment	3-5
Figure 3-3: The Channel Readout	3-9
Figure 3-4: Waveform Selection Priority	3-10
Figure 3-5: Scaling and Positioning	3-11
Figure 3-6: Vertical Readouts and Channel Menu	3-12
Figure 3-7: Record View and Time Base Readouts	3-14
Figure 3-8: Horizontal Controls	3-15
Figure 3-9: Acquisition: Input Analog Signal, Sample, and Digitize .	3-18
Figure 3-10: Several Points May be Acquired for Each Point Used .	3-18
Figure 3-11: Real-Time Sampling	3-18
Figure 3-12: Equivalent-Time Sampling	3-19
Figure 3-13: How the Acquisition Modes Work	3-22

Figure 3-14: Acquisition Menu and Readout	3-24
Figure 3-15: Acquire Menu — Stop After	3-27
Figure 3-16: Aliasing	3-28
Figure 3-17: Display Menu — Style	3-31
Figure 3-18: Trigger Point and Level Indicators	3-32
Figure 3-19: Display Menu — Setting	3-35
Figure 3-20: Display Menu — Palette Colors	3-37
Figure 3-21: Display Menu — Map Reference Colors	3-38
Figure 3-22: Display Menu — Restore Colors	3-39
Figure 3-23: Zoom Mode with Horizontal Lock Set to None	3-41
Figure 3-24: Dual Window (Preview) Mode	3-43
Figure 3-25: Dual Zoom — Shown Dual Window (Preview) Mode ..	3-44
Figure 3-26: Normal DSO Acquisition and Display Mode Versus InstaVu Mode	3-46
Figure 3-27: InstaVu Display	3-47
Figure 3-28: Fast Frame	3-49
Figure 3-29: Horizontal Menu — FastFrame Setup	3-49
Figure 3-30: Triggered Versus Untriggered Displays	3-51
Figure 3-31: Trigger Holdoff Time Ensures Valid Triggering	3-54
Figure 3-32: Slope and Level Controls Help Define the Trigger	3-55
Figure 3-33: TRIGGER Controls and Status Lights	3-56
Figure 3-34: Example Trigger Readouts — Edge Trigger Selected ..	3-58
Figure 3-35: Record View, Trigger Position, and Trigger Level Bar Readouts	3-58
Figure 3-36: Edge Trigger Readouts	3-59
Figure 3-37: Main Trigger Menu — Edge Type	3-60
Figure 3-38: Violation Zones for Setup/Hold Triggering	3-65
Figure 3-39: Logic Trigger Readouts — State Class Selected	3-66
Figure 3-40: Logic Trigger Menu	3-67
Figure 3-41: Logic Trigger Menu — Time Qualified TRUE	3-69
Figure 3-42: Triggering on a Setup/Hold Time Violation	3-72
Figure 3-43: Pulse Trigger Readouts	3-73
Figure 3-44: Main Trigger Menu — Glitch Class	3-75
Figure 3-45: Main Trigger Menu — Runt Class	3-78
Figure 3-46: Main Trigger Menu — Slew Rate Class	3-82
Figure 3-47: Delayed Runs After Main	3-85
Figure 3-48: Delayed Triggerable	3-85
Figure 3-49: How the Delayed Triggers Work	3-87
Figure 3-50: Delayed Trigger Menu	3-88

Figure 3-51: Graticule, Cursor and Automated Measurements	3-91
Figure 3-52: Measurement Readouts	3-94
Figure 3-53: Measure Menu	3-95
Figure 3-54: Measure Menu — Gating	3-96
Figure 3-55: Measure Menu — Reference Levels	3-97
Figure 3-56: Measure Delay Menu — Delay To	3-98
Figure 3-57: Snapshot Menu and Readout	3-100
Figure 3-58: Cursor Types	3-101
Figure 3-59: Cursor Modes	3-102
Figure 3-60: H Bars Cursor Menu and Readouts	3-103
Figure 3-61: Paired Cursor Menu and Readouts	3-104
Figure 3-62: Performing a Signal Path Compensation	3-108
Figure 3-63: Probe Cal Menu and Gain Compensation Display	3-111
Figure 3-64: Re-use Probe Calibration Data Menu	3-113
Figure 3-65: Save/Recall Setup Menu	3-116
Figure 3-66: Save Waveform Menu	3-119
Figure 3-67: More Menu	3-120
Figure 3-68: File Utilities	3-123
Figure 3-69: File System — Labeling Menu	3-124
Figure 3-70: Utility Menu — System I/O	3-127
Figure 3-71: Hardcopy Formats	3-128
Figure 3-72: Date and Time Display	3-129
Figure 3-73: Connecting the Oscilloscope Directly to the Hardcopy Device	3-130
Figure 3-74: Connecting the Oscilloscope and Hardcopy Device Via a PC	3-132
Figure 3-75: Typical GPIB Network Configuration	3-135
Figure 3-76: Stacking GPIB Connectors	3-135
Figure 3-77: Connecting the Oscilloscope to a Controller	3-136
Figure 3-78: Utility Menu	3-137
Figure 3-79: Status Menu — System	3-140
Figure 3-80: Banner Display	3-140
Figure 3-81: Initial Help Screen	3-141
Figure 3-82: Comparing a Waveform to a Limit Template	3-143
Figure 3-83: Acquire Menu — Create Limit Test Template	3-145
Figure 3-84: More Menu	3-148
Figure 3-85: Dual Waveform Math Main and Side Menus	3-149
Figure 3-86: System Response to an Impulse	3-152
Figure 3-87: Define FFT Waveform Menu	3-153

Figure 3-88: FFT Math Waveform in Math1	3-154
Figure 3-89: Cursor Measurement of an FFT Waveform	3-156
Figure 3-90: Waveform Record vs. FFT Time Domain Record	3-157
Figure 3-91: FFT Time Domain Record vs. FFT Frequency Domain Record	3-158
Figure 3-92: How Aliased Frequencies Appear in an FFT	3-162
Figure 3-93: Windowing the FFT Time Domain Record	3-165
Figure 3-94: FFT Windows and Bandpass Characteristics	3-167
Figure 3-95: Derivative Math Waveform	3-169
Figure 3-96: Peak-Peak Amplitude Measurement of a Derivative Waveform	3-170
Figure 3-97: Integral Math Waveform	3-173
Figure 3-98: H Bars Cursors Measure an Integral Math Waveform	3-174
Figure B-1: MCross Calculations	B-4
Figure B-2: Fall Time	B-7
Figure B-3: Rise Time	B-11
Figure B-4: Choosing Minima or Maxima to Use for Envelope Measurements	B-13
Figure E-1: Typical High Voltage Probes	E-2
Figure E-2: A6303 Current Probe Used in the AM 503S Opt. 03 ...	E-4

List of Tables

Table 1-1: Key Features and Differences of Models	1-2
Table 1-2: Fuse and Fuse Cap Part Numbers	1-5
Table 3-1: Autoset Defaults	3-7
Table 3-2: How Interleaving Affects Sample Rate	3-21
Table 3-3: Additional Resolution Bits	3-24
Table 3-4: TDS 500B and TDS 700A Sampling Mode Selection (When Fit to Screen is Off)	3-26
Table 3-5: XY Format Pairs	3-34
Table 3-6: Pattern and State Logic	3-64
Table 3-7: Pulse Trigger Definitions	3-74
Table 3-8: Measurement Definitions	3-92
Table 3-9: Probe Cal Status	3-114
Table A-1: Options	A-1
Table A-2: Standard Accessories	A-4
Table A-3: Optional Accessories	A-5
Table A-4: Accessory Software	A-7
Table D-1: Factory Initialization Defaults	D-1
Table F-1: External Inspection Check List	F-2