
Reference

HP 71450B/1B/2B
Optical Spectrum
Analyzers

HP Part No. 70950-90062
Edition 1
Printed in USA August 1996

1400 Fountaingrove Parkway,
Santa Rosa, CA
95403-1799, USA

Notice. The information contained in this document is subject to change without notice. Hewlett-Packard makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Restricted Rights Legend. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c) (1) and (c) (2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

© Copyright Hewlett-Packard Company 1996
All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Contents

1. Specifications and Characteristics	
Definitions of Terms	1-3
Specifications: HP 71450B/1B/2B (HP 70950B/1B/2B)	1-6
Additional Specifications: HP 71451B (HP 70951B)	1-10
Specifications: Optional Current Source	1-13
Specifications: Optional Built-In White Light Source	1-14
Specifications: Optional Swept Polarization Dependent Loss Kit	1-15
General Specifications	1-16
Regulatory Information	1-17
Notice for Germany: Noise Declaration	1-19
2. Menu Maps	
Amptd Menu	2-4
BW, Swp Menu	2-5
Marker Menu	2-6
Misc Menu	2-8
State Menu	2-10
Traces Menu	2-12
Waveln Menu	2-13
USER Menu's DFB Advanced Measurement Program	2-14
USER Menu's FP Advanced Measurement Program	2-15
USER Menu's LED Advanced Measurement Program	2-16
USER Menu's PDL Advanced Measurement Program	2-17
3. Dictionary Reference	
Alphabetical Listing	3-3
	3-3
 	3-3
	3-3
1/T	3-4
3-DIMEN On Off	3-4
A $\leftarrow$ A - B	3-5
A $\leftarrow$ A+B	3-6
A $\leftarrow$ (A-B)-C	3-6
A $\leftarrow$ (A - B)-C+DL	3-7

A ← A - B+DL	3-7
A ← A - C	3-8
A ← A - C+DL	3-9
A ← A*DL/(A+B)	3-9
A ← A*DL/(A+B+C)	3-10
A ← A*DL/B	3-10
A ← A*DL/C	3-11
A ← DL*(A+B)/C	3-12
Λ METER On Off	3-12
Λ UNITS AutoMan	3-13
A XCH B	3-13
A XCH C	3-13
ACT	3-14
ACTIVE MARKER	3-14
adc sync	3-15
ADC SYNC OUT	3-17
adc trigger	3-17
ADCTRIG AC	3-19
ADCTRIG DELAY	3-19
ADCTRIG FREE	3-20
ADCTRIG NEGEDGE	3-21
ADCTRIG POSEDGE	3-21
ALIGN PRESET	3-22
AMP REF OFFSET	3-22
AMPCOR -> LOWER	3-23
AMPCOR-> UPPER	3-24
AMPCOR On Off	3-25
Amptd	3-25
AMPTD VALUE	3-26
ANALOG OUT	3-26
ANALYZR TEST	3-26
ANOTATN On Off	3-27
ANY CHR	3-27
AT MKR On Off	3-28
autmeas state	3-28
Auto	3-30
AUTO ALIGN	3-30
AUTO ALIGN	3-31
AUTO MEASURE	3-31
AUTO MEASURE	3-32
AUTO SCALE	3-32

AUTOPTS ALIGN	3-33
AUTORNG On Off	3-34
AUTZERO On Off	3-35
B ← B-DL	3-35
B XCH C	3-36
BEEPER On Off	3-36
BLANK A	3-37
BLANK B	3-37
BLANK C	3-38
BLANK TRACES	3-39
BW, Swp	3-39
C ← B	3-39
cal menu	3-40
CAL POWER	3-42
cal setup	3-43
CAL WAVELEN	3-43
CAL WVL AT PIT	3-44
CALC + DISPLAY	3-44
CALC On Off	3-45
CANCEL	3-46
catalog & MSI	3-46
<u>CENTER</u>	3-49
CENTER	3-49
CHANGE PREFIX	3-50
CHOP On Off	3-50
CLEAR TO END	3-51
CLEAR WRT A	3-52
CLEAR WRT B	3-52
CLEAR WRT C	3-53
CLOSEST PEAK	3-53
CLOSEST PIT	3-54
COMMAND	3-54
CONFIG	3-56
CONFIRM DELETE	3-57
CONFIRM ERASE	3-57
CONT	3-57
CONT SWEEP	3-58
current source	3-58
CURRENT SOURCE	3-62
-> CWL	3-62
Δ ->CWL STEP	3-63

DB/DIV AutoMan	3-63
dBm	3-64
debug	3-64
DEBUG FAST	3-65
DEBUG On Off	3-66
DEBUG SLOW	3-66
DEFINE USR KEY	3-67
DELETE ALL	3-67
DELETE CHAR	3-68
DELETE or	3-68
DELETE SEGMENT	3-69
DELTA	3-69
DETECTR Ext Int	3-70
DFB	3-71
DISPLAY	3-72
DISPOSE USER	3-73
distrib menu	3-73
DISTRIB On Off	3-74
DSP LIN On Off	3-74
DSPLY B ON OFF	3-75
DUTY CYCLE %	3-75
EDIT FUNCDEF	3-76
ENTER COMMAND	3-77
enter limit	3-77
ENTER LINE	3-77
ENVELOPE	3-78
ENVELOPE MKR BW	3-78
ERASE ALL	3-79
erase/ restart	3-80
ERR	3-80
execute DLP	3-80
EXIT	3-81
EXT	3-81
EXT TRIG IN	3-82
EXTEND STATE	3-82
extnded align	3-83
FLAT	3-83
FORMAT	3-84
FP	3-84
FREQ	3-86
FULL SPAN	3-87

GATESWP On Off	3-87
GAUSSIAN	3-89
grat control	3-89
GRAT On Off	3-90
GRATSCR On Off	3-90
HELP On Off	3-90
HIGHEST PEAK	3-91
HOLD	3-91
HOLD	3-92
HORZ OFFSET	3-92
HP-MSIB CARD	3-93
HPIB DISK	3-94
HSWP IN/OUT	3-95
HYS LEVEL	3-96
IGEN LIMIT	3-96
IGEN On Off	3-97
INIT PDL	3-98
INSERT or	3-99
INSTR	3-99
instr modes	3-101
INSTR PRESET	3-101
INT WIN On Off	3-102
INTEGRT FROM PK	3-102
integrt menu	3-103
INTEGRT STOP WL	3-103
INTEGRT STRT WL	3-104
INTRNL MEMORY	3-104
key control	3-105
LAST SEGMENT	3-106
LCL	3-106
LED	3-107
LEFT PEAK	3-109
LEFT PIT	3-110
light source	3-110
lim <-> ampcor	3-111
limit lines	3-112
LIMITS On Off	3-112
LINE	3-113
LINEAR	3-113
LINES On Off	3-114
LOAD FILE	3-114

LOCKOUT ANOTATN	3-115
LOG dB/DIV	3-116
LORENZ	3-116
LOWER-> AMPCOR	3-117
LSN	3-118
MANUAL ALIGN	3-118
Marker	3-119
marker excursn	3-119
marker readout	3-120
MARKER TUNE	3-120
MAX HOLD A	3-121
MEAS	3-122
MENU	3-122
MIN HOLD A	3-123
MINIMUM PEAK	3-123
MINIMUM PIT	3-124
MINIMUM POINT	3-124
MK STOP On Off	3-125
MKNOISE On Off	3-125
MKPAUSE On Off	3-126
MKR BW On Off	3-126
MKR BW On Off	3-127
mkw bw/zoom bw	3-128
MKR NRM On Off	3-128
MKR TRA A B C	3-129
MONO INPUT	3-129
MONOCHROMATOR INPUT	3-130
MONOCHROMATOR OUTPUT	3-130
NEXT PAGE	3-131
NEXT PEAK	3-131
NEXT PEAK	3-131
NEXT PIT	3-132
NEXT SEGMENT	3-132
NO. OF STATES	3-133
NORM On Off	3-134
NORMAL ON/OFF	3-134
oneshot math	3-135
OPTICAL INPUT	3-135
OPTIMIZ	3-136
OPTSENS On Off	3-136
ORDER AutoMan	3-137

OSA	3-140
OSA PULSE	3-140
P STATE On Off	3-141
PARTIAL ERASE	3-141
PAUSE	3-142
PD INPUT	3-142
PD MEAS ON OFF	3-143
PDL	3-144
PEAK EXCURSN	3-145
PEAK SEARCH	3-146
PEAK THRESH	3-146
PEAKS On Off	3-147
PERIOD	3-147
PERSIST On Off	3-148
PHOTO DIODE	3-149
PHOTODETECTOR INPUT	3-150
PIT EXCURSN	3-150
pit,min markers	3-151
PLOT	3-151
POINT	3-152
POWER FOR CAL	3-152
POWER METER	3-153
POWERON IP	3-154
POWERON LAST	3-154
poweron menu	3-155
POWERON RECALL	3-155
PRESEL	3-156
PRESET USER	3-157
prev menu	3-157
PRINT	3-158
PULSE WIDTH	3-158
PURGE FILE	3-159
PWR CAL On Off	3-159
RB/SPAN RATIO	3-160
recall	3-161
recall from	3-162
RECALL LIMIT	3-162
RECALL MEMORY	3-163
RECALL STATE	3-163
RECALL TRACE A	3-164
RECALL USER	3-165

RECALL USERKEY	3-165
-> REF	3-166
REF LEVEL	3-166
REF LVL	3-166
REF LVL POSN	3-167
REL LEFT	3-167
REL RIGHT	3-168
RELATIV On Off	3-168
REPLACE or	3-169
RES BW	3-169
RES BW AutoMan	3-170
RESTART	3-170
RIGHT PEAK	3-171
RIGHT PIT	3-172
RMT	3-172
ROM VERSION	3-172
save	3-173
SAVE LIMIT	3-174
SAVE MEMORY	3-175
SAVE STATE	3-175
save to	3-176
SAVE TRACE A	3-176
SAVE USER	3-177
SAVE USERKEY	3-178
SELECT CHAR	3-178
SELECT SEGMENT	3-179
SENS	3-179
SENS AutoMan	3-180
service	3-180
SERVICE REQUEST	3-181
show states	3-182
SIG TRK LIMIT	3-182
SIG TRK On Off	3-183
SINGLE SWEEP	3-183
SLOPE	3-184
SMSR On Off	3-185
SOURCE On Off	3-185
SPACE	3-186
Δ ->SPAN	3-186
SPAN	3-187
SPAN	3-187

SPAN AutoMan	3-188
SRQ	3-189
<u>START</u>	3-189
START	3-189
STARTUP AutoMan	3-190
State	3-190
STATE	3-191
STEP	3-191
STM/RESP	3-192
<u>STOP</u>	3-192
STOP	3-193
STORE A	3-193
STORE THRU->B	3-194
STP BND On Off	3-194
SWEEP On Off	3-195
SWPTIME	3-195
SWPTIME AutoMan	3-196
sync out	3-196
TAKE SWEEP	3-199
THRESHD On Off	3-200
TITLE	3-200
TLK	3-201
<u>TO CENTER</u>	3-201
<u>TO REF LEVEL</u>	3-202
trace A B C	3-202
TRACE LENGTH	3-202
trace linmath	3-203
trace logmath	3-203
TRACE PRESET	3-204
Traces	3-204
TRANS-Z IN	3-205
TRIGGER FREE	3-205
TRNSZLK On Off	3-206
type	3-207
units menu	3-207
UPPER-> AMPCOR	3-208
UPPER/LOWER	3-209
<u>USER</u>	3-209
USERCAL PRESET	3-210
VERSION	3-210
VERT OFFSET	3-211

VID AVG On Off	3-211
VID BW AutoMan	3-212
VID LIN On Off	3-213
VIDEO	3-214
VIDEO LEVEL	3-215
VIEW A	3-215
VIEW B	3-216
VIEW C	3-216
W LIGHT ALIGN	3-217
WARNING On Off	3-218
WATT	3-218
WAVELEN	3-219
WAVELEN FOR CAL	3-219
WAVELEN OFFSET	3-220
WAVELEN VALUE	3-221
Waveln	3-221
WHITE On Off	3-221
WL CAL On Off	3-222
WL LIM On Off	3-222
WL STEP AutoMan	3-223
X	3-224
ZERO	3-224
ZOOM TO RES BW	3-224
 4. Error Messages	
User Application Errors (0001 – 0999)	4-3
Operating Errors (2000 – 2999)	4-4
Hardware- Warning Errors (6000 – 6999)	4-14
Hardware- Broken Errors (7000 – 7999)	4-16
Computation Errors (8000 – 8999)	4-19
Factory-Use Only Errors (9000 – 9999)	4-20
Warning Messages (16001 – 16012)	4-21
 5. Concepts	
Block Diagram	5-3
Detection Techniques	5-5
Sensitivity Coupling States	5-6
Sweep Time Operation	5-12
Optical versus Microwave Spectrum Analyzers	5-14