

# Table of Contents

List of Figures .....	vii
List of Tables .....	ix

---

## Getting Started

<b>Getting Started .....</b>	<b>1-1</b>
<b>This Manual .....</b>	<b>1-1</b>
Getting Started .....	1-1
Command Syntax .....	1-1
Commands .....	1-1
Status and Events .....	1-2
Programming Examples .....	1-2
<b>Setting Up Remote Communications .....</b>	<b>1-3</b>
Connecting the Instrument to a GPIB Network .....	1-3
Connecting the Instrument to an RS-232-C Device .....	1-6

---

## Syntax and Commands

<b>Command Syntax .....</b>	<b>2-1</b>
<b>Command Structure .....</b>	<b>2-2</b>
<b>Data Element Definitions .....</b>	<b>2-3</b>
<b>Set and Query Commands .....</b>	<b>2-5</b>
Set Commands .....	2-5
Queries .....	2-7
Multiple Query Forms .....	2-8
Using Query Responses as Commands .....	2-8
Concatenating Commands .....	2-9
Defining New Command Strings .....	2-10
Measurement (<meas>) Commands .....	2-10
Waveforms and Traces .....	2-10
<b>Command Processing Conventions .....</b>	<b>2-11</b>
Abbreviating Commands .....	2-11
Getting Long-form or Short-form Responses .....	2-11
Using Upper and Lower Case .....	2-12
Using Quoted Strings .....	2-13
Terminating Messages .....	2-14
Using White Space .....	2-14
Null Commands .....	2-15
I/O Buffers .....	2-15

## Table of Contents

GPIB Specific Conventions .....	2-16
RS-232-C Specific Conventions .....	2-16
<b>Command Groups .....</b>	<b>2-23</b>
<b>Functional Groups .....</b>	<b>2-23</b>
<b>Acquisition Commands .....</b>	<b>2-26</b>
<b>Calibration Commands .....</b>	<b>2-28</b>
<b>Channel/Vertical Commands .....</b>	<b>2-28</b>
<b>Cursor Commands .....</b>	<b>2-29</b>
Cursors and the Selected Trace .....	2-29
Cursor Positioning Methods .....	2-30
<b>Data Transfer Commands .....</b>	<b>2-30</b>
Retrieving Trace Data From the Instrument .....	2-31
Sending Trace Data to the Instrument .....	2-31
<b>Diagnostics Commands .....</b>	<b>2-32</b>
<b>Display and Color Commands .....</b>	<b>2-32</b>
<b>External I/O Commands .....</b>	<b>2-33</b>
<b>Label and Text Commands .....</b>	<b>2-34</b>
<b>Measurement Commands .....</b>	<b>2-34</b>
Selecting Measurements .....	2-34
Measurement Modes: Hardware, Software, and Software Statistics .....	2-35
Measurement Statistics .....	2-35
Comparing Measurement With References .....	2-35
Measurement (<meas>) Commands .....	2-36
Measurement Parameter Group .....	2-39
Measurement Execution Commands .....	2-44
<b>Miscellaneous/ System Commands .....</b>	<b>2-45</b>
<b>Status Queries and Event Commands .....</b>	<b>2-46</b>
<b>Time Base/ Horizontal Commands .....</b>	<b>2-46</b>
<b>Trace and Settings Commands .....</b>	<b>2-47</b>
<b>Triggering Commands .....</b>	<b>2-48</b>
<b>Alphabetic Command Summary .....</b>	<b>2-49</b>
<b>Command Set .....</b>	<b>2-69</b>

---

## Status and Events

<b>Status and Events .....</b>	<b>3-1</b>
<b>Status Reporting .....</b>	<b>3-1</b>
Status Byte Definition .....	3-2
RQS Command .....	3-2
SRQMASK Command .....	3-3
STByte? Query-Only Command .....	3-3
RS232 Verbose Mode .....	3-3
System Status Conditions .....	3-4
Status Byte Codes .....	3-4

<b>Event Reporting</b> .....	3-6
Event Code Descriptions .....	3-6
<b>Command Errors</b> .....	3-8
<b>Execution Errors</b> .....	3-10
<b>Internal Errors</b> .....	3-19
<b>System Events</b> .....	3-20
<b>Execution Warnings</b> .....	3-21
<b>Internal Warnings</b> .....	3-24

## Examples

<b>Programming Examples</b> .....	4-1
<b>Introduction to the Examples</b> .....	4-1
Organization of the Examples .....	4-1
Software and Computer Hardware Needed .....	4-2
Equipment Needed .....	4-2
<b>Installing the Example Software</b> .....	4-3
Hard Disk Installation .....	4-3
Floppy Disk Installation .....	4-4
<b>Running the Example Software</b> .....	4-5
<b>Exiting the Example Software</b> .....	4-5
<b>MENU.BAS Program</b> .....	4-6
<b>Example 1:</b> Displaying a Trace .....	4-7
<b>Example 2: Managing Multiple Traces</b> .....	4-11
<b>Example 3: Defining Complex Traces</b> .....	4-17
<b>Example 4: Using Signal Processing &amp; Transferring a Waveform</b> .....	4-23
<b>Example 5: Taking Automated Measurements</b> .....	4-31
<b>Example 6: Taking Delay Measurements</b> .....	4-37
<b>Example 7: Taking Delta-Delay Measurements</b> .....	4-43
<b>Example 8: Comparing Traces</b> .....	4-49
<b>Example 9: Taking TDR Measurements</b> .....	4-55

## Appendices

<b>Appendix A:</b>	
<b>Improving System Performance</b> .....	A-1
<b>Components of System Performance</b> .....	A-2
Instrument Setup Time .....	A-3
Data Acquisition Time .....	A-4
Data Transfer Time .....	A-5
Data Processing Time .....	A-7
Human Interaction Time .....	A-8

<b>Appendix B:</b>		
<b>Reserved Words</b> .....		B-1
<b>Appendix C:</b>		
<b>Character Sets</b> .....		C-1
<b>Appendix D:</b>		
<b>Utility Programs</b> .....		D-1
<b>Setup</b> .....		D-1
Interface Configuration .....		D-1
Computer Interface Configurations .....		D-2
<b>IBM PC-Compatible Controller</b> .....		D-4
Taking Measurements .....		D-4
Transferring a Binary Waveform into an Array .....		D-4
Storing and Recalling Front Panel Settings .....		D-4
Handling SRQs .....		D-5
Transferring a String to the CSA 803A/11801B Display .....		D-5
<b>HP 200 &amp; 300 Series Controllers</b> .....		D-6
Taking Measurements .....		D-6
Transferring a Binary Waveform into an Array .....		D-6
Storing and Recalling Front Panel Settings .....		D-6
Handling SRQs .....		D-7
Transferring a String to the CSA 803A/11801B Display .....		D-7
<b>Appendix E:</b>		
<b>GPIB Interface Functions</b> .....		E-1
<b>GPIB Interface Functions Implemented</b> .....		E-1
<b>Appendix F:</b>		
<b>System Event Handling</b> .....		F-1
<b>Status and Event Reporting System</b> .....		F-1
Port-dependent Events .....		F-1
Port-independent Events .....		F-2
System Event Handling Priorities .....		F-2
<b>RS-232-C Event Handling</b> .....		F-3
Reading the RS-232-C Current Event Registers .....		F-3
<b>GPIB Event Handling</b> .....		F-4
Event Reporting When GPIB RQS is Off .....		F-4
Reading the GPIB Current Event Registers (RQS Off) .....		F-4
Event Reporting When GPIB RQS is On .....		F-6
Reading the GPIB Current Event Registers (RQS On) .....		F-6
Summary of Important Points When RQS is On .....		F-7
Turning On the RQS Icon with SRQMASK USER .....		F-7
Events Reported at Instrument Power-On .....		F-9

---

## Glossary and Index

<b>Glossary</b> .....	G-1
<b>Index</b> .....	I-1

# List of Figures

Figure 1-1: Common Message Elements .....	1-1
Figure 1-2: Functional Groupings and an Alphabetical List of Commands .....	1-2
Figure 1-3: Location of GPIB Connector on Rear Panel .....	1-3
Figure 1-4: How GPIB Connectors can be Stacked Together .....	1-4
Figure 1-5: Typical GPIB Settings on the GPIB/RS232C Parameters Pop-Up Menu .....	1-5
Figure 1-6: The GPIB/RS232C Parameters Pop-Up Menu .....	1-8
Figure 2-1: Example of Syntax Elements .....	2-2
Figure 2-2: X, Y Touch Panel Screen Coordinates .....	2-70
Figure 2-3: Bits in a Pixel Block Data Byte .....	2-80
Figure 2-4: Binary Data Transfer .....	2-101
Figure 2-5: Data Window Parameters .....	2-110
Figure 2-6: Graticule X, Y Coordinates .....	2-113
Figure 2-7: Graticule X, Y Coordinates .....	2-118
Figure 2-8: Histogram Window Parameters .....	2-133
Figure 2-9: Graticule X, Y Coordinates .....	2-137
Figure 2-10: Examples of Wildcard Usage .....	2-148
Figure 2-11: TEXT X:,Y: Display Coordinates .....	2-217
Figure 4-1: Connections for Example 1 .....	4-7
Figure 4-2: Connections for Example 2 .....	4-11
Figure 4-3: Connections for Example 3 .....	4-17
Figure 4-4: Connections for Example 4 .....	4-23
Figure 4-5: Connections for Example 5 .....	4-31
Figure 4-6: Connections for Example 6 .....	4-37
Figure 4-7: Connections for Example 7 .....	4-43
Figure 4-8: Connections for Example 8 .....	4-49
Figure 4-9: Connections for Example 9 .....	4-55
Figure A-1: System Performance Components .....	A-2
Figure A-2: Components of Data Acquisition Time .....	A-4
Figure D-1: GPIB Driver-Board (GPIB) Settings .....	D-2
Figure D-2: GPIB Driver-Device (CSA 803A or 11801B) Settings .....	D-3
Figure F-1: Remote Interface Status Reporting System Block Diagram .....	F-1
Figure F-2: RS-232-C Event Handling .....	F-3
Figure F-3: GPIB Event Handling .....	F-5
Figure F-4: RQS Icon on the Front Panel Display .....	F-7

# List of Tables

Table 1-1: RS-232-C Pin Mappings .....	1-6
Table 1-2: CSA 803A and 11801B RS-232-C Pin-out .....	1-7
Table 2-1: BNF Symbols .....	2-1
Table 2-2: Numeric Data Types .....	2-3
Table 2-3: Global Data Types .....	2-3
Table 2-4: Quoted String Data Type .....	2-4
Table 2-5: Non-printable ASCII Character Representations .....	2-19
Table 2-6: Examples of Responses with VERBOSE ON .....	2-20
Table 2-7: Examples of Responses with VERBOSE OFF .....	2-20
Table 2-8: RS-232-C I/O Errors .....	2-22
Table 2-9: Functional Groups in the Command Set .....	2-23
Table 2-10: Command Groups .....	2-24
Table 2-11: Signal Acquisition Commands .....	2-26
Table 2-12: Trace Function Commands .....	2-26
Table 2-13: Acquisition Parameter Commands .....	2-27
Table 2-14: System Calibration and Status Commands .....	2-28
Table 2-15: Channel/Vertical Commands .....	2-28
Table 2-16: Cursor Commands .....	2-29
Table 2-17: Data Transfer Execution Commands .....	2-30
Table 2-18: Data Transfer Parameter Commands .....	2-30
Table 2-19: Diagnostics Commands .....	2-32
Table 2-20: Display and Color Commands .....	2-32
Table 2-21: Interface Commands .....	2-33
Table 2-22: Printer Commands .....	2-33
Table 2-23: Label and Text Commands .....	2-34
Table 2-24: Timing Measurements .....	2-36
Table 2-25: Amplitude Measurements .....	2-37
Table 2-26: Area/Energy Measurements .....	2-38
Table 2-27: Frequency Domain Measurements .....	2-38
Table 2-28: Measurement Parameter (MPARAM) Links .....	2-39
Table 2-29: Measurement Parameter Interactions .....	2-42
Table 2-30: Measurement Execution Commands .....	2-44
Table 2-31: Front Panel Commands .....	2-45
Table 2-32: System Commands .....	2-45
Table 2-33: Status Queries .....	2-46
Table 2-34: Event Commands .....	2-46
Table 2-35: Time Base/Horizontal Commands .....	2-46
Table 2-36: Trace Commands .....	2-47
Table 2-37: Front Panel Settings Commands .....	2-48
Table 2-38: Triggering Commands .....	2-48

Table 2-39: Alphabetical Command Summary .....	2-50
Table 2-40: Front Panel Button X, Y Coordinates .....	2-70
Table 2-41: Predefined Trace Colors .....	2-72
Table 2-42: Valid HMAg Values .....	2-72
Table 2-43: ADJ? Predefined Responses .....	2-74
Table 2-44: Default ALTinkjet Color Assignments .....	2-76
Table 2-45: Examples Using AVG .....	2-79
Table 2-46: Data Repetition Encoding .....	2-81
Table 2-47: Color Indexes .....	2-90
Table 2-48: REMAINING Means for CONDacq TYPE .....	2-93
Table 2-49: Acquisition Types .....	2-94
Table 2-50: Predefined CURVe? Data Values .....	2-101
Table 2-51: Default Preamble Parameters .....	2-102
Table 2-52: Restricted Expansion String Characters .....	2-105
Table 2-53: Acceptable and Illegal Recursion .....	2-106
Table 2-54: Predefined Logical Names .....	2-106
Table 2-55: XDIV Ranges .....	2-120
Table 2-56: Positioning Accuracy Qualifiers .....	2-120
Table 2-57: Examples of ENV Usage .....	2-125
Table 2-58: Default HP 560C Color Assignments .....	2-141
Table 2-59: Default Plotter Pen Assignments .....	2-142
Table 2-60: MAINPos Range .....	2-151
Table 2-61: Software Measurement Accuracy Qualifiers .....	2-163
Table 2-62: <meas> Measurement Types .....	2-165
Table 2-63: Parameter Ranges for Distal .....	2-167
Table 2-64: Parameter Range for Mesial .....	2-171
Table 2-65: MLEvelmode Examples .....	2-172
Table 2-66: SRQMASK Lists .....	2-200
Table 2-67: Default TEK4692 Color Assignments .....	2-209
Table 2-68: Examples of 4692 Index Coding .....	2-210
Table 2-69: Default Inkjet Colors Assigned by Color .....	2-211
Table 2-70: Colors Associated With 4696 Color Numbers .....	2-212
Table 2-71: Default TEK4697 Color Assignments .....	2-213
Table 2-72: Examples of 4697 Index Coding .....	2-214
Table 2-73: Escape Character Default Colors .....	2-216
Table 2-74: Checksum Types .....	2-230
Table 2-75: Trace Types Displayable in Integer Mode .....	2-236
Table 2-76: Traces Not Displayable in Integer Mode .....	2-237
Table 3-1: Status Byte Definitions .....	3-2
Table 3-2: Binary and Decimal Status Byte Codes .....	3-5
Table 3-3: Formatting Symbols .....	3-6
Table 3-4: Command Errors .....	3-8
Table 3-5: Execution Errors .....	3-10
Table 3-6: Internal Errors .....	3-19

Table 3-7: System Events .....	3-20
Table 3-8: Execution Warnings .....	3-21
Table 3-9: Internal Warnings .....	3-24
Table D-1: CSA 803A or 11801B Interface Configuration .....	D-1
Table E-1: GPIB Functions .....	E-1
Table F-1: Event Priorities .....	F-2