

User Manual

4/42

Tektronix

OA 5000 Series
Optical Attenuators

070-7612-01

Manutenzione Strumenti

Contents

Welcome	i
Contents	iii
List of Figures	vii
List of Tables	ix
Safety	xi

A Quick Tour

Installation	1-1
Removing the OA 5000	1-2
A Quick Tour	1-3
Preset the OA 5000	1-3
Storing and Recalling Settings	1-4
Setting a Reference Value	1-5
Settings at Power Up	1-6

User Reference

Operator Overview	2-1
The User Reference Section	2-1
Enabling/Disabling Attenuation	2-3
Setting Attenuation Levels	2-5
Specifying the Wavelength	2-5
Setting the Attenuation Level	2-6
Setting the Attenuation Level to Minimum	2-7
Setting the GPIB Address	2-9
Setting the Reference Level	2-11
Measuring Insertion Loss	2-12
Approximating Signal Power	2-12
Storing and Recalling Attenuation Levels	2-15

Programming

Setting Up the Instrument	3-1
Controllers	3-1
Using the GPIB Interface	3-1
GPIB Requirements	3-2
Setting the GPIB Address	3-3
Command Syntax	3-5
Clearing the OA 5000	3-5
Command and Query Structure	3-6
Commands	3-7
Queries	3-7
Headers in Query Responses	3-7
Command Entry	3-8
Abbreviating Commands	3-8
Concatenating Commands	3-8
Message Terminators	3-9
Argument Types	3-10
Block Arguments	3-10
Numeric Arguments	3-11
Syntax Diagrams	3-11
Commands	3-13
Common Commands and Queries	3-13
Device Commands and Queries	3-14
ADJusting? (Query Only)	3-15
ALLev? (Query Only)	3-15
ATTenuation	3-16
BLRN	3-17
*CAL? (Query Only)	3-18
*CLS (No Query Form)	3-18
DESE	3-19
DISable	3-20
DISPlay	3-20
*ESE	3-21
*ESR? (Query Only)	3-22
EVEnt? (Query Only)	3-22
EVMSG? (Query Only)	3-23
EVQty? (Query Only)	3-23
FACTORY (No Query Form)	3-24
HEADer	3-25
*IDN? (Query Only)	3-26
*LRN? or SET?	3-26
*OPC	3-27

*PSC	3-28
RECall (No Query Form)	3-28
REFeRence	3-29
*RST (No Query Form)	3-29
*SRE	3-30
*STB? (Query Only)	3-31
STORe (Store Attenuation)	3-31
*TST? (Query Only)	3-32
VERBOSE	3-33
*WAI (No Query Form)	3-34
WAVelength	3-34
Status and Events	3-37
Registers	3-37
Status Registers	3-37
Enable Registers	3-39
The Enable Registers and the *PSC Command	3-40
Queues	3-41
The Output Queue	3-41
The Event Queue	3-41
Event Handling Sequence	3-41
Conflicts	3-43
Messages	3-44

Appendices

Appendix A: Accessories	A-1
Standard Accessories	A-1
Optional Accessories	A-1
Appendix B: Specifications	A-3
Appendix C: Interface Specifications	A-7
Interface Messages	A-7
Character Set (ASCII Chart)	A-8
GPIO Function Subsets	A-9
Appendix D: Using the *OPC Query/Command	A-11
Appendix E: Packing for Shipment	A-13
Appendix F: Maintenance	A-15
Cleaning the Optical Ports	A-15
Changing the Optical Port Connectors	A-17
Appendix G: Product Verification	A-21

Equipment List	A-21
Power Up	A-22
Display Modes	A-23
GPIB Address Setting	A-24
Shutter Attenuation and the DISABLE button	A-25
Insertion Loss (Long Wavelengths)	A-26
Insertion Loss (Short Wavelengths)	A-27
Attenuation Range	A-27
Repeatability and Accuracy	A-28
Appendix H: Replaceable Parts	A-31
Parts Ordering Information	A-31
Using the Replaceable Parts List	A-31
Item Names	A-31
Indentation System	A-32
Abbreviations	A-32

Index

Index	I-1
-------------	-----

Change Information

List of Figures

Figure 1-1: Installing the OA 5000 into the Power Module	1-2
Figure 1-2: OA 5002 Front Panel	1-4
Figure 2-1: OA 5002 Front Panel	2-2
Figure 2-2: The Location of the DISABLE Button	2-3
Figure 2-3: Setting Attenuation Levels	2-5
Figure 2-4: The Location of the ADDR (SET) Button	2-9
Figure 2-5: The Location of the SET REF Button	2-11
Figure 2-6: The Location of the STORE and RECALL Buttons	2-15
Figure 3-1: GPIB Connector Location	3-2
Figure 3-2: Typical GPIB Network Configurations	3-2
Figure 3-3: Command Message Elements	3-6
Figure 3-4: Block Argument Example	3-10
Figure 3-5: Typical Syntax Diagrams	3-11
Figure 3-6: The Standard Event Status Register (SESR)	3-38
Figure 3-7: The Status Byte Register (SBR)	3-39
Figure 3-8: The Device Event Status Enable Register (DESER)	3-40
Figure 3-9: The Event Status Enable Register (ESER)	3-40
Figure 3-10: The Service Request Enable Register (SRER)	3-40
Figure 3-11: Status and Event Handling Process	3-42
Figure A-1: Removing the Optical Bulkhead Connector	A-16
Figure A-2: FC Optical Bulkhead Assembly	A-17
Figure A-3: ST Optical Bulkhead Assembly	A-18
Figure A-4: DIN 47256 Optical Bulkhead Assembly	A-18
Figure A-5: SC Optical Bulkhead Assembly	A-19
Figure A-6: OA 5000 Replaceable Parts	A-33

List of Tables

Table 3-1: BNF Symbols and Meanings	3-5
Table 3-2: Command Message Elements	3-6
Table 3-3: Comparison of Header On and Off Responses	3-7
Table 3-4: Commands Common to All GPIB Devices and Supported by the OA 5000 Series	3-13
Table 3-5: OA 5000 Device Commands and Parameters	3-14
Table 3-6: FACTORY Front Panel Settings	3-25
Table 3-7: Results from *TST?	3-32
Table 3-8: SESR Bit Functions	3-38
Table 3-9: SBR Bit Functions	3-39
Table 3-10: No Event Messages	3-44
Table 3-11: Command Error Messages — CME Bit 5	3-44
Table 3-12: Execution Error Messages — EXE Bit 4	3-46
Table 3-13: Device Error Messages — DDE Bit 3	3-46
Table 3-14: System Event Messages — QYE Bit 2	3-46
Table 3-15: Execution Warning Messages — EXE Bit 4	3-47
Table A-1: Optical Characteristics	A-3
Table A-2: Mechanical Characteristics	A-4
Table A-3: Environmental Performance	A-4
Table A-4: OA 5000 Standard Interface Messages	A-7
Table A-5: The ASCII Character Set	A-8